

SZAFKA DS02 - SCHEMAT STREF

The diagram illustrates the wiring and zone configuration for the SZAFKA DS02 fire alarm control panel. It shows the main unit with various input and output terminals, and the corresponding connections to the fire alarm zones. The zones are labeled as SP16, SP17, SP18, SP19, SP20, SP21, SP22, and SP23. The connections are made through a terminal block and a relay. The diagram also includes a legend for the symbols used: SP (Smoke Detector), DS (Detector), and DS02 (Control Panel).

Legenda:

- SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23: Strefy dymu (Smoke Detector)
- DS02: Strefa dymu (Control Panel)

Opis diagramu:

Diagram przedstawia szafkę DS02 z podziałem na strefy dymu. W górnej części widoczne są strefy SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23. W dolnej części znajduje się szafka DS02 z podziałem na strefy dymu. W prawej części diagramu widoczne są symbole: SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23, DS02.

Legenda:

- SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23: Strefy dymu
- DS02: Strefa dymu

Opis diagramu:

Diagram przedstawia szafkę DS02 z podziałem na strefy dymu. W górnej części widoczne są strefy SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23. W dolnej części znajduje się szafka DS02 z podziałem na strefy dymu. W prawej części diagramu widoczne są symbole: SP16, SP17, SP18, SP19, SP20, SP21, SP22, SP23, DS02.

[illegible]